


Background

- To enhance occupant protection, there is a need to start looking at other injuries
- Ankle injuries are common and major cost to the society
- Need a way to measure injury to lower legs and ankle injuries
- Current lower legs do not have instrumentation in the ankles
- Current seating procedures places the foot and ankle in a non-neutral position (non-humanlike)





- Thor lower legs can be used to measure lower extremities injury for both the 50th and 5th female dummies.
- Three rotations at the ankle
 - □ Inversion/eversion (X axis)
 - □ Plantar flexion/dorsiflexion (Y axis)
 - □ Internal/external rotation (Z axis)
- Have a preferred "neutral" position (0, -15, 0 deg) which allows for a more realistic foot angle







Current Seating Procedures
Used in FMVSS 208





- Seat at mid-track, lowest height and position
- Seat back angle set by manufacturer
- Right foot on accelerator pedal
- Left foot on footrest, or toe on toeboard, or flat on floor pan



5

Government Industry Meeting – May 2007



5th Percentile Female Dummy (standard/Denton lower legs)

- Seat at full-forward, mid angle, lowest height
- Seat back angle determined by head level
- Right foot on accelerator pedal
- Left foot is flat on toe pan



Enhanced Lower Legs and Current

Seating Position

- When dummy is placed in mid track, the THOR legs possibly may not achieve the neutral position.
 - The feet are sometimes put in dorsiflexion when placed on accelerator pedal and/or footrest
 - □ Pre-loading of ankle/foot is undesireable
- Determined we need to research a new seating procedure



7







Assumptions about Human Seating

- What do people do when they get in an unfamiliar vehicle?
 - Move the seat back
 - ☐ Get in the seat, adjust the height
 - ☐ Move seat forward till foot reaches the pedals
 - □ Adjust seat back until head is level





Dummy Based Seating Positioning Goals

- Seat the dummy based on vehicle footwell and size of occupant
- Repeatable procedures
- Right foot in contact with accelerator pedal
- All feet in neutral positions, without any preloading of the feet
- All heels are on the floorpan



9

Government Industry Meeting – May 2007



Seat and Feet Final Positions

- Determine the driver seat track location based on the right
 - □ heel on the floor pan
 - □ foot contacting the accelerator pedal
 - □ foot in the neutral position
- Determine the passenger seat track location by getting feet
 - □ close to the firewall
 - □ neutral
- Avoid placing driver's left foot on brake or clutch pedals
- Left foot is placed symmetric to the right foot



10





Driver Procedure Summary

- Start with the seat full rear, cushion at midangle
 - □ Position dummy's H-Point and pelvis at this location
- Place dummy's feet in neutral
 Aim right foot towards the accelerator pedal
- Move left foot to avoid overlap with any pedals
- Move forward till right foot contacts accelerator pedal
- Adjust the left foot to be
 - $\hfill\Box$ symmetrical about midsaggital plane or
 - □ limited by contact with side-wall or foot-rest
- Adjust the seat back to make head level



Government Industry Meeting – May 2007

٠,

Examples of Driver's Side Footwell Layouts













Government Industry Meeting – May 2007

12



Passenger Procedure Summary

- Start with the seat full rear, cushion at mid-angle, feet together
- Pitch toes downwards towards the floor
- Move forward till feet touch toepan or seat is full forward
- Lift toes back up to neutral position
- Move forward (if possible)
- Spread feet apart symmetrically until either contact with interior or knees 10.6" apart (6.7" for 5th F)
- Adjust the seat back to make head level






50th Percentile Male Procedure Development


- Vehicles used in the study
 - □2002 Ford Focus
 - □2005 Cadillac STS
 - □2005 VW Jetta
 - □ 2005 Honda Ridgeline
 - □ 2005 Honda Odyssey








15











































Observations

- Use of Thor legs adds complexity but are usable and valuable tools
- Repeatability of dummy-based is similar to mid-track/full-forward procedures
- Dummy-based procedures more likely to have:
 - □ thighs on the seat
 - □ heels on the floorpan
 - ☐ feet in neutral
 - □ right foot on the accelerator pedal



31





Observations Continued

- 50th Male
 - □ Dummy's left foot is not always on the footrest
 - □ Driver seat is usually rear of mid-track
- 5th Female
 - □ Seat position was sometimes slightly rearward of full forward
 - □ Feet in neutral



33

Government Industry Meeting – May 2007



Thanks for your attention!

Allison E. Louden NHTSA / VRTC allison.louden@dot.gov 937-666-4511

