

7. A uniaxial accelerometer unit can be attached directly to the mounting location provided on the right side of the tibia tube to measure the Y-axis acceleration. Use two #0-80 x 1/4" SHCS {0.05} to attach the uniaxial accelerometer to the flat mounting area on the right hand side of the Lower Tibia Tube, as shown in **Figure 3.8**.




Figure #3.8 - Attaching Y-axis accelerometer

8. The Tibia Guard (T1LLM014) is mounted to the front of the Lower Leg assembly using a 1/4-28 x 7/8" BHSCS {5/32} in the top mounting hole and a 1/4-28 x 5/8" BHSCS {5/32} in the lower mounting hole, as shown in **Figure 3.9**. The triaxial accelerometer wire is routed out the hole in the tibia guard on the right side.




Figure #3.9 - Tibia Guard Assembly

9. An exploded view of the Achilles Spring Tube assembly is shown in **Figure 3.10**. Refer to drawing T1LLM300 for further details .



Figure #3.10 - Exploded View of Achilles Spring Tube

10. Place the Load Cell Base Washer (T1LLM315) into the counterbore at the bottom of the Spring Tube Base (T1LLM310), as shown in **Figure 3.11**.



Figure #3.11 - Load Cell Base Washer

11. Place the mock uniaxial load cell (T1LLM020) into the bottom of the Spring Tube Base, as shown in **Figure 3.12**.



Figure #3.12 - Mock Uniaxial Load Cell

12. Place the Achilles Spring Base Cap (T1LLM314) onto the Mock Load Cell with the raised button facing away from the load cell, as shown in **Figure 3.13**.



Figure #3.13 - Spring Base Cap

13. Screw the Achilles Spring Tube (T1LLM311) into the top of the Spring Tube Base and tighten securely as shown in **Figure 3.14**.




Figure #3.14 - Thread Spring Tube into Base

14. Position the Elastomeric Spring Element (T1LLM316) inside the compression spring. Slide the compression spring assembly (Spring & T1LLM313) into the Spring Tube with the Spring Cap toward the open end, as shown in **Figure 3.15**.




Figure #3.15 - Slide compression spring into the Spring Tube

15. Insert the Soft Foam Compression Element (T1LLM317) on top of the Spring, as shown in **Figure 3.16**.